


# PowerView<sup>™</sup> - Model PV101-A, Version 2.3



# **Features**

- For electronic engines and equipment applications using SAE J1939 Controller Area Network
- Displays over 50 standard SAE J1939 parameters broadcast by engine and transmission ECU's
- Displays active and ECU-stored faults with text description for diagnosing equipment malfunctions
- Simple connection to optional components

The **PowerView Model PV101**, Murphy's powerful display in the J1939 MurphyLink® family of components, provides a window into modern electronic engines and transmissions.

The PV101 display is a multifunction tool which enables equipment operators to view many standard engine and transmission parameters as well as active and stored trouble codes. The display can show either a single parameter or a quadrant display showing four parameters simultaneously. Diagnostic capabilities include codes with text translation for the most common fault conditions. The enhanced alarm indication has ultra-bright alarm and shutdown LEDs (amber and red). The PV101-A features include:

**OEM Menu** - This Password protected menu offers access to MODBUS Setup, Engine Speed Control ON/OFF, and other critical menu items that require restricted access.

**Multiple language options** – Russian, Czech, Brazilian Portuguese, Chinese, and Japanese models have been added to the line of existing languages (English, Spanish, French, German, and Italian).

**Fuel Sender Input** – select between backlight dimmer function or fuel level. Can be calibrated to use non-Murphy fuel senders.

**Service Reminders** – 5 service reminders allow users to set hours for: Change Engine Oil, Change Air Filters, Change Hydraulic Oil, Service Engine, and Service Machine.

**Select Source Address** – select the exact address the PV101 will claim on the Bus.

Select CANBUS Data Rate - allows user to select CANBUS data rate.

Other components in the MurphyLink system include micro-processor-based PowerView Analog (PVA) Gages for displaying critical engine data broadcast by an electronic engine or transmission's Engine Control Unit (ECU); engine RPM, oil pressure, coolant temperature, system voltage, and a combination audible alarm and relay unit for warning and shutdown annunciation. Up to 32 components may be linked to the PowerView using a simple daisy chain wire connection scheme using RS485. The PowerView and all connected components can be powered by either 12 or 24-volt systems.

# **Display Parameters**

The following are some of the engine and transmission parameters displayed by the PowerView (when applicable, consult engine or transmission manufacturer for SAE J1939 supported parameters). The PowerView can display these parameters in all available languages, as well as in English or Metric units.

- · Engine RPM
- · Engine Hours
- · Fuel Rate
- System Voltage
- · % Engine Load at the Current RPM
- · Coolant Temperature
- · Catalyst Level

- Oil Pressure
- Fuel Economy
- · Throttle Position
- Engine Manifold Air Temperature
- · Current Fuel Consumption
- · Transmission Oil Pressure
- NMEA 2000 GPS Parameters
- · Transmission Oil Temperature
- Transmission Gear Position
- · Active Service codes
- Stored Service Codes (when supported)
- View Engine Configuration Parameters

In order to consistently bring you the highest quality, full featured products, we reserve the right to change our specifications and designs at any time. MURPHY products and the Murphy logo are registered and/or common law trademarks of Murphy Industries, LLC. This document, including textual matter and illustrations, is copyright protected by Murphy Industries, LLC, with all rights reserved. (c) 2011 Murphy Industries, LLC.

# **Specifications**

# **Operating Voltage**

- 6.5 VDC minimum to 32 VDC maximum
- 8 VDC minimum to 32 VDC maximum with optional PVM gages

Reversed Polarity: Withstands reversed battery terminal polarity indefinitely within operating temperatures.

#### **Environmental**

Operating Temperature: -40 to +85°C (-40° to +185°F) Display Viewing Temperature: -29 to +85°C (-20° to +185°F) Storage Temperature: -40 to 85°C (-40° to +185°F) Environmental Sealing: IP68, ±5 PSI (± 34.4 kPa)

### **Power Supply Operating Current**

(@ 14VDC) 52 mA min; 300 mA max (@ 32VDC) 1A max (with LCD heater)

CAN Bus: SAE J1939 compliant Case: Polycarbonate / polyester

Maximum Panel Thickness: 3/8 inch (9.6 mm)

**Product Dimensions** 

#### Auxiliary RS485 Communications Port

- User configurable as Modbus MASTER or Modbus RTU SLAVE
- MASTER ACTIVE (default) drives optional PVA or PVM gages
- SLAVE ACTIVE offers user adjustable communication parameters

### Resistive Input: (user selectable as one of the following)

Backlighting Potentiometer: 1 K Ohm, 1/4 W

Murphy Fuel Sender: 33 Ohm full, 240 Ohm empty set from the factory or programmable to work with non-Murphy fuel senders

Fuel Sender Input: 33 Ohm full, 240 Ohm empty set standard from factory for use with Murphy Fuel sender. Programmable for use with non-Murphy fuel senders.


Shipping Weights (all models): 1 Lb. (450 g.)

# Shipping Dimensions (all models):

5 x 6 x 6 in. (127 x 152 x 152 mm)

Clamp: PBT

Connectors: 6-pin Deutsch DT Series



# **How to Order**

Part Number	Model Number	Description	Languages Available
78700244	PV101-A	Murphy Standard	English, Spanish, French, Italian, German
78700396	PV101-A-M01	Murphy Standard Russian	English, Russian, French, German, Spanish
78700409	PV101-A-M02	Murphy Standard Chinese*	English, Chinese
78700411	PV101-A-M03	Murphy Standard Japanese*	English, Japanese

<sup>\*</sup>Added features not available in these language models.

### **FW MURPHY**

P.O. Box 470248 Tulsa, Oklahoma 74147 USA Phone: +1 918 317 4100 Fax: +1 918 317 4266

E-mail: sales@fwmurphy.com

INDUSTRIAL PANEL DIVISION

Fax: +1 918 317 4124 E-mail: ipdsales@fwmurphy.com

#### MURPHY POWER IGNITION

Web site: www.murphy-pi.com

#### **CONTROL SYSTEMS & SERVICES DIVISION**

P.O. Box 1819

Rosenberg, Texas 77471 USA

Phone: +1 281 633 4500 Fax: +1 281 633 4588

E-mail: css-solutions@fwmurphy.com

# FRANK W. MURPHY LTD.

Church Road, Laverstock Salisbury, SP1 1QZ, UK

Phone: +44 1722 410055 Fax: +44 1722 410088 E-mail: sales@fwmurphy.co.uk

Web site: www.fwmurphy.co.uk

# FW MURPHY INSTRUMENTS (HANGZHOU) CO., LTD.

77 23rd Street

Hangzhou Economic & Technological Development Area Hangzhou, Zhejiang, 310018, China

Phone: +86 571 8788 6060 Fax: +86 571 8684 8878 E-mail: apsales@fwmurphy.com



#### COMPUTRONIC CONTROLS

41 - 46 Railway Terrace Nechells, Birmingham, B7 5NG, UK E-mail: sales@computroniccontrols.com Web site: www.computroniccontrols.com



ww.fwmurphy.com